LIMITED TIME Enjoy your DU Group mega offers with Flash Reader!

Install DuB GO on an Android Tablet or Phone (Step-by-Step Guide)

Overview

Before starting DU GO, make sure your device is compatible. It is crucial to ensure your Android tablet or phone is set up correctly to avoid any issues during the installation process. This guide will walk you through the steps to check your device's compatibility and configure it for DU GO. Follow these steps carefully to ensure a smooth installation. Let's get started!

Increase the Speed of Your Android Tablet or Phone

Before starting DU GO, it's important to optimize the performance of your Android tablet or phone. This will help ensure a smooth and efficient installation process. Follow these steps to increase the speed of your device:

1) Remove the Mobile Device SIM Card

If your mobile device has a SIM card slot and it's not in use, it's a good idea to remove it. Removing the SIM card can help improve the performance of your device by reducing unnecessary background processes. Make sure to power off your device before removing the SIM card.

Note: If you're not sure how to remove the SIM card, see your mobile device's instruction manual or look for instructions in these [Android support guides](#).

2) Enable Developer Mode

You can access hidden settings on your mobile device by enabling developer mode. These hidden settings can help you optimize your device's performance. Here's how to enable it:

- Tap the Android Settings app.
- Tap the Android Settings app.
- Tap the About device option.
- Tap the About device option.
- Tap the Build number option seven times.
- Tap the Build number option seven times.

Once enabled, you'll see a new **Developer options** item in the Settings.

3) Turn Off Animation Settings

By disabling the display animations, you'll be able to decrease the time it takes to navigate through the different menus and settings on your mobile device.

Follow these steps to disable all display animations:

- Tap the Android Settings app.
- Tap the Android Settings app.
- Tap the Developer options item.
- Tap the Developer options item.
- Set the following options to **Animation off**:
  - Window animation scale
  - Transition animation scale
  - Animator duration scale

4) Enable Unknown Sources

By default, you're only able to install apps from the Google Play Store. By enabling the unknown sources option, you'll be able to install apps from other sources, such as the DU Group app or APK files. It's easy to do, and you'll only need to do it once.

- Tap the Android Settings app.
- Tap the Android Settings app.
- Tap the Security & privacy or **Android settings** in the Settings menu.
- Tap the Security & privacy or **Android settings** in the Settings menu.
- Set the **Unknown sources** setting to enable it.
- Set the **Unknown sources** setting to enable it.

Note: You can download DU APK files for DU GO, DU GO 2, and other apps from websites like APKMirror or APKMonkey. See the instructions in DU GO Version 2 on the Android Installation page.

5) Disable App Auto Updates

By default, the Google Play Store is going to automatically install updates for your installed apps. You can disable this feature to prevent any unwanted updates from interfering with your DU GO setup. Here's how to disable app auto updates:

- Tap the Google Play Store app.
- Tap the Google Play Store app.
- Tap the Settings option.
- Tap the Settings option.
- Tap the **Network preferences** or **Network & internet** option.
- Tap the **Network preferences** or **Network & internet** option.
- Tap the **Auto-update apps** option.
- Tap the **Auto-update apps** option.
- Select the **Don't auto-update apps** option.
- Select the **Don't auto-update apps** option.

6) Uninstall or Disable Unused Apps

To free up more resources for DU GO, uninstall or disable apps that you don't want going on. You can uninstall or disable these apps in the app settings section and temporarily on your mobile device.

- Tap the Android Settings app.
- Tap the Android Settings app.
- Tap the Apps option.
- Tap the Apps option.
- Select the app you want to uninstall or disable.
- Select the app you want to uninstall or disable.
- Tap the **Uninstall** or **Disable** button.
- Tap the **Uninstall** or **Disable** button.

Note: Some of the apps are system apps and cannot be uninstalled unless you root your mobile device. If an app cannot be uninstalled, you can **Disable** button instead of **Uninstall** button.

7) Disable App Notifications

By default, apps you install on to take up to display notifications when certain events occur.After a few days, you'll start to receive a lot of notifications from apps you've installed. You can disable these notifications.

Follow these steps to disable the notifications for an app:

- Tap the Android Settings app.
- Tap the Android Settings app.
- Tap **Notifications & status bar** or **Sound & notifications** in the Settings menu.
- Tap **Notifications & status bar** or **Sound & notifications** in the Settings menu.
- Tap **Notifications management** or **App notifications**.
- Tap **Notifications management** or **App notifications**.

Note: The exact steps may vary slightly depending on the device and the version of Android it's running. Before you're using.

- Select the app you want to disable notifications for.
- Select the app you want to disable notifications for.
- Disable the **Allow notifications** setting or turn off the notifications you'd like to ignore (if the different options are available).
- Disable the **Allow notifications** setting or turn off the notifications you'd like to ignore (if the different options are available).

Note: The exact steps may vary slightly depending on the device and the version of Android it's running. Before you're using.

8) Increase Display Sleep Time

By default, your mobile device will turn off the screen after a set of units quickly in order to conserve battery power. When your mobile device is idle. If that becomes counterproductive to you, you can increase the idle time so you don't have to keep waking your device up. Here's how to increase the display sleep time on your device:

- Tap the Android Settings app.
- Tap the Android Settings app.
- Tap the **Display** in the Settings menu.
- Tap the **Display** in the Settings menu.
- Choose the amount of time you want the time period you'd like your mobile device to wait before turning off the screen.
- Choose the amount of time you want the time period you'd like your mobile device to wait before turning off the screen.

9) Downgrade DU GO

Note: The only reason you'll want to be running an old/older mobile device that is not able to run the current version of DU GO. Also the step 2 you'd like to see the current version of DU GO.

- Tap the Android Settings app.
- Tap the Android Settings app.
- Tap the **DU GO** option.
- Tap the **DU GO** option.
- Tap the **Uninstall** button.
- Tap the **Uninstall** button.

Now you're ready to install DU GO. You can download the latest version from the Google Play Store or install the downloaded APK file and tap it to install it.

Note: Downgrading DU GO is currently a reliable solution but some will no more reliable because.

10) Configure These Settings to Improve DU GO Performance

- Follow these **Recommended Settings**, refering to **Regular Mode** for more information.
- Follow these **Recommended Settings**, refering to **Regular Mode** for more information.

Note: This setting might not be available depending on which DU device you're flying.

- Disable the **Cache Locally When Recording** setting. With this setting disabled, DU GO will not save a copy of recorded videos to your mobile device's storage. This will help improve performance.
- Disable the **Cache Locally When Recording** setting. With this setting disabled, DU GO will not save a copy of recorded videos to your mobile device's storage. This will help improve performance.

Note: If you're flying a DJI Spark, this setting will be named **Cache to SD Card**.

- If you were previously using the accurate video results, then clear the video cache to free up storage space and improve performance.
- If you were previously using the accurate video results, then clear the video cache to free up storage space and improve performance.

- Disable the **Gyroscope Map Coordinates (For Cinco Maneuver)** setting if you're not flying a Cinco.
- Disable the **Gyroscope Map Coordinates (For Cinco Maneuver)** setting if you're not flying a Cinco.

- Use the **Offline Map** feature to download a some versions of DU GO (for DJI GO 4 V4.3.36 if you're using a version of DJI GO that does not include the Offline Map feature, then install an other version of DU GO or DJI GO 4 that does include the Offline Map feature). Then download an offline map of the area you're planning to fly in. Using an offline map will help improve performance if the area where you're flying has poor internet connectivity. For more information, see the Offline Maps page.
- Use the **Offline Map** feature to download a some versions of DU GO (for DJI GO 4 V4.3.36 if you're using a version of DJI GO that does not include the Offline Map feature, then install an other version of DU GO or DJI GO 4 that does include the Offline Map feature). Then download an offline map of the area you're planning to fly in. Using an offline map will help improve performance if the area where you're flying has poor internet connectivity. For more information, see the Offline Maps page.

Do These Things Before Every Flight

1) Close Down All Running Apps

Before starting DU GO, tap the square button at the bottom of the screen to view a list of running apps and close the memory while to see which all running apps and close apps you're not using. Closing unused apps can help free up memory and improve the performance of DU GO.

2) Disable Screen Recorder

Unless you're sure your mobile device will perform well while running both DU GO and a screen recorder, disable the screen recorder before flying. Screen recorders can cause DU GO to crash or lag. If you're not sure if you have one, see if there's one of the more powerful Android mobile devices.

3) Enable Airplane Mode

Swipe down from the top of your mobile device's screen and enable airplane mode. This will turn off your mobile device's cellular connection and help improve the performance of DU GO. Airplane mode will also help keep you from receiving phone calls and text messages while making airplane mode.

4) Maximize Screen Brightness

When flying outdoors, it's be easier to your mobile device screen when the brightness is on the maximum setting. Swipe down from the top of your mobile device's screen, and locate the "Auto" shortcut of brightness, and disable it. Then drag the brightness slider all the way to the right.

5) Turn Up the Volume

Turn the volume up using the volume controls on the right side of your mobile device. This will ensure that you won't miss important audio that occurs in DU GO (like when the home point is recorded).

6) Configure USB Port Settings

If your mobile device is connected to the remote controller via a USB cable, you should choose the following settings. Otherwise, you may not be able to record videos to your mobile device.

- Tap the Android Settings app.
- Tap the Android Settings app.
- Tap the Developer options item.
- Tap the Developer options item.
- Set the **Default USB configuration** option to **File transfer**.
- Set the **Default USB configuration** option to **File transfer**.