

Product model*

Phantom 4 (CN)

Parts

- ☐ Phantom 4 100W battery charger
- ☐ Phantom 4 battery
- ☒ Phantom4 aircraft (exclude RC, camera, battery and battery charger) 07ddd350a11307
- ☒ Phantom 4 gimbal camera 07RDD340S200GC
- ☐ Phantom 4 remote controller top cover (with silk print)
- ☐ Micro SD card (16G)
- ☐ Data cable
- ☐ Paddle