




« HOW TO SET COMBINATION »

- 1.) Make sure the zippers are not locked in position when resetting the lock.
- 2.) Press the **reset pin** located on the bottom side of the lock with a small pointed object such as a pen. Press pin until a "click" sound confirms reset.



- 3.) Set desired 3-digit combination. (Rotating dials will have some resistance once ready for new combination)
- 4.) Use the **push** button to activate new combination.