Preflight checklist

- ♦ Phantom & R/C battery charged
- → iPad charged
- ♦ Propellers installed and tightened
- ♦ Remove gimbal lock
- ♦ Gimbal not obstructed (grass)
- ♦ iPad volume to MAX
- ♦ iPad to R/C cable attached
- ♦ iPad Wifi & BT OFF
- ♦ R/C ON
- ♦ R/C in **P-Mode**
- ♦ Phantom ON
- ◆ Launch DJI Pilot app

Check values:

- ♦ Compass status
- ♦ IMU values (0, 1, 1400-1600)
- ♦ Gain values
- ♦ Max height
- ♦ RTH height (depends on flight location)
- ◆ R/C EXP & Gain (0,5-0,4-0,5)
- ♦ VPS ON (if indoor flight)
- ♦ Satellite status
- ♦ Format SD card
- **♦ CHECK HOME POINT**

Takeoff

Hover 30 seconds & check stability

Normal		
R G Y Red, Green ar Alternatively	nd Yellow Flash	Turning On and Self Diagnostic Testing
G Y Green and Yellow	Flash Alternatively	y Warming Up
G ····· Green Flashes Slowly		Safe to Fly (P-mode with GPS and Vision Positioning)
G X2 ····· Green Flashes T	wice	Safe to Fly (P-mode with Vision Positioning but without GPS)
Y ····· Yellow Flashes Slowly		Safe to Fly (A-mode but No GPS and Vision Positioning)
Warning		
Y Fast Yellow Flashing		Remote Controller's Signal Lost
RSlow Red Flashing		Low Battery Warning
R ······ Fast Red Flashing		Critical Battery Warning
R ······ Red Flashing Alternatively		IMU Error
R — Solid Red		Critical Error
$\begin{picture}(6,0)(0,0)(0,0) \put(0,0){\line(0,0){10}} \put(0,0){\line(0,0){10$	Flash Alternatively	Compass Calibration Required
Status LED	Alarm	Remote Controller Status
R — Solid Red	♪ Chime	The remote controller is disconnected from the aircraft.
G — Solid Green	♪ Chime	The remote controller is connected to the aircraft.
® ····· Slow Blinking Red	D-D-D	Remote controller error.
R G / R Y Red and Green/ Red and Yellow Alternate Blinks	None	HD downlink is disrupted.
RTH LED	Sound	Remote Controller Status
W Solid White	Chime	Aircraft is returning home.
W Blinking White	D · · ·	Sending Return-to-Home command to the aircraft.
W Blinking White	DD	Return-to-Home procedure in progress.