

RF-V42 SMS Command	Command Function
pw,123456,center,number#	***** has been set for the master number Successfully
sos2,number#	Emergency contact number 2 has been set successfully
sos3,number#	Emergency contact number 3 has been set successfully
sos4,number#	Emergency contact number 4 has been set successfully
gprsgps,0#	Close GPS positioniong,only GSM standby
gprsgps,1#	Open GPS positioniong(default)
lz,0,8#	Change the SMS language to English, the first digital is for language, 1 is Chinese,0 is English. the second digital is for timezone
url#	Check the location
upload,digital#	Set interval of the position data upload the unit is second
led,1#	Turn on the indicator light
led,0#	Turn off the indicator light
dnd,1#	Has closed the anti harassment function, please be careful to use
dnd,0#	Has opened the anti harassment function
ans,0#	The device is in hands-free push-to-talk (PTT) mode currently
ans,1#	The device is in auto-answer (hands-free) monitoring mode currently
ans,2#	The device is in silent monitoring mode currently.
pic,1#	Taking the picture
sosp,1#	It will take picture when SOS
sosp,0#	It will not take picture when SOS
mod,0#	The alert send to APP only
mod,1#	The alert send to APP,SMS and then call
mod,2#	The alert send to APP, and call
mod,3#	The alert send to APP,SMS
ts#	check the device information
lsn,0#	LED light induction has been closed
lsn,1#	LED light induction has been started
von,1#	Level 1 vibration sensor alarm ON
von,2#	Level 2 vibration sensor alarm ON
von,3#	Level 3 vibration sensor alarm ON
von,4#	Level 4 vibration sensor alarm ON
von,0#	Vibration sensing alarm function is closed
non,1#	Sound sensing alarm function is opened
non,0#	Sound sensing alarm function is closed
fon,0#	Fall down alarm OFF
fon,1#	Fall down alarm ON,please wear this device correctly incase of misalarm. which will affect standby time
reboot#	The device will be reboot soon
factory#	The device will power off after 30s
apn,apndata,username,password,plmncode#	Configure the apn setting